
Exporting/Importing Settings From One Logger To Another

MMS Version 12.0.1
Revision 9.2022

Unzip the RevImportExport Zip file to the Revcord Logger Desktop to be duplicated.
There are two applications:

1. RevExport - Used to export the settings from the older recorder
2. RevImport - Used to import the exported (older recorder) settings to the new recorder

RevExport

1. Run the “RevExport” application as Admin.
 - a. This creates a folder called “Backup”. It will backup the Registry and Database(SQL).
 - b. It will take approximately 5 to 10 minutes.
 - c. Once the backup is done the application will automatically close.

RevImport

1. First compress Backup folder to a zip file,
 - a. (Be sure to copy the whole folder to the zip file)
2. Then complete a File transfer of the Zip File to the final destination on the new system
3. Run the “RevImport” application as Admin.
 - a. It will import the Registry and will replace the Database(SQL) and ShConfig (Synway) Configuration file.
 - b. Once Import is done the application will automatically close.
 - c. Other data C:\\Disstech will **NOT** be imported. That is for backup purposes only.
 - d. If wanted those files are available manually.